





**4** + 39 02 942 1724

info@trime.it

www.trime.it

#### Mast & Floodlights spare parts



LED Floodlight 320W

Code:

AC000\_E026\_019



Floodlight top support

Code:

LED04\_C000\_014ZN



Floodlight lower support

Code:

LED04\_C000\_011ZN



Anti-drag spacer

Code:

AS000\_M023\_001



Multiposition handle

Code:

AC000\_M000\_007



Junction box

Code:

AS000\_E006\_001



Coiled cable

Code:

AC000\_E006\_016



**Buble level** 

Code:

AC000\_M016\_002



Mast rotation lock pin

Code:

AC000\_M000\_003



Hydraulic cylinder

Code:

AS000\_I025\_001



Led power connector

Code:

AC000\_E006\_085



Mast rope L.1460 mm full eyelet

Code:

AC000\_M021\_005



Mast rope L.1440 mm full eyelet

Code:

AC000\_M021\_012



Mast rope L.1440 mm full / dug eyelet

Code:

AC000\_M021\_004



full / dug eyelet

Mast rope L.1415 mm

AC000\_M021\_006

Mast rope L.1385 mm full / dug eyelet Code:

AC000\_M021\_007



Angular runner

AS000\_M000\_005



Angular runner reinforcement

PFI08\_C031\_012ZN



Rubber handle


Code:

AC000\_P037\_001



Pulley D.58

AC000\_M021\_001



Pulley D.62 Code:

AC000\_M021\_003

Pulley D.63 Code:

AC000\_M021\_008









## Hydraulic unit spare parts



Hydraulic tank cap

Code:

AS-EC1270112



Electrovalve solenoid body

Code:

AS-F720002B1



Electrovalve energizing coil

Code:

AS-C150001OA



Electrovalve energizing coil plug

Code:

AS-EC167002



250Bar valve

Code:

AS-F733006250

## Electrical spare parts



DSE3110 controller

Code:

AC000\_E014\_001



DSEL401 controller

Code:

AC000\_E014\_003



USB cable

Code:

AC000\_E000\_064



DSE gateway

Code:

AC000\_E014\_004



Battery charger

Code:

AC000\_E006\_012



Fuel level gauge

Code:

AC000\_E015\_005



RCBO 13A

Code:

AC000\_E012\_028



Lamp switch

Code:

AC000\_E012\_027



8 modules cover

Code:

AC000\_E000\_008



10 modules cover

Code:

AC000\_E000\_020



Timer

Code:

AC000\_E000\_053



Light sensor

Code:

AC000\_E016\_002



Light sensor capacitor

Code:

AC000\_E000\_070



Mast control buttons

Code:

SI000\_G006\_006



1 poles switch

Code:

SI000\_G006\_003







**4** + 39 02 942 1724

info@trime.it

www.trime.it

## Electrical spare parts



Generator/Mains selector Code:

AC000\_E006\_057



Inlet plug 230V 16A

Code:

AC000\_E011\_005



**Outlet socket** 230V 16A

Code:

AC000\_E011\_007



**Emergency stop** button

Code:

SI000\_G006\_010



Thermal circuit breaker

Code:

AC000\_E012\_013



12V 70A relay

AC000\_E000\_041



12V 30A relay

AC000\_E000\_040



Contactor switch

AC000\_E006\_054



Fuse holder

AC000\_E012\_030



2A fuse

Code:

AC000\_E012\_014



Earth post

Code:


AC000\_M038\_035



**Battery** 

Code:

AC000\_E000\_027



Junction box

Code:

AS000\_E006\_003



#### Engine spare parts



25µF capacitor

Code:

L-EX541511025



Battery charger regulator

Code:

K-RP20153710



**Engine Stop Timer** 

Code:

K-T007031410



Fan belt

Code:

K-1588197010



Air filter element

Code:

K-1921511220









## Engine spare parts



Cooling Water Expansion Code: K-1553172402



Fuel filter

Code:
K-1522143170



Fuel lift pump

Code:
K-R140151352



Fuel pre-filter

Code:

AC000\_M001\_008



Engine oil drain pump

Code:

AS000\_M000\_060



Oil drain pipe kit

Code:

AC000\_G001\_001



Anti-vibration buffer

Code:

AC000\_M024\_054



Oil filter

Code:

K-W21ESO1500

## Chassis spare parts



Fuel tank cap

Code:

AC000\_M000\_028



Fuel sender unit

Code:

AC000\_E006\_025



Handle with lock

Code:

AC000\_M000\_017



Door hinge

Code:

AC000\_M000\_009



Door retention rope

Code:

XECOK2\_M009\_161



Stabilizer lock pin

Code

AC000\_M000\_086



Left stabilizer beam

Code:

XECOK2\_C000\_120ZN



Right stabilizer beam

Code:

XECOK2\_C000\_119ZN



Front stabilizer

Code

XECOK2\_C003\_200



Rear stabilizer

Code:

XECOK2\_C003\_156







**\** + 39 02 942 1724

info@trime.it

www.trime.it

### Chassis spare parts



Stabilizer crank handle

Code:

AC000\_M000\_016



Pin lock with spring

Code:

AC000\_M000\_077



Handle

Code:

AC000\_M000\_005



Plastic cover

Code:

XECO\_AS009\_058



Stabilizer rubber buffer

Code:

XECOK2\_R008\_190



Mudguards Rubber buffer

Code:

XECOK2\_R008\_189



Exhaust rain cover

Code:

AC000\_M000\_080



Radiator cap cover

Code:

AC000\_M001\_035



Radiator cap cover retention rope

Code:

AS000\_G031\_083



Jockey wheel

Code:

AC000\_T003\_003



AMOSS switch

Code:

SI000\_E006\_009



Coiled cable & electrical connector for towing

Code: AC000\_E050\_017 Code: AC000\_E013\_001



Trailer socket kit

Code: AC000\_E050\_031 Code: AC000\_E050\_016



Adapter

Code:

AC000\_E000\_062



Junction box

Code:

AC000\_G006\_001



Right mudguard

Code:

XECOK2\_C004\_069



Left mudguard

Code:

XECOK2\_C004\_070



Wheel

Code:

AC000\_T003\_001



White reflector

| Code

AC000\_T013\_001




Orange reflector

Code

AC000\_T013\_002







info@trime.it







## Chassis spare parts



Multi-function rear right light Code: AC000\_E013\_005



Multi-function rear left light Code: AC000\_E013\_006



Multi-function rear right light Code: AC000\_E013\_007



Multi-function rear left light Code: AC000\_E013\_008



Multi-function rear light Code: SE000\_E013\_001





Lighting Tower Specialist

# TRIME s.r.l.

Strada per Robecco, snc 20081 Cassinetta di Lugagnano (MI) - ITALY Tel. +39 02 942 1724

www.trime.it - info@trime.it