

genuine spare parts
fast moving items




X-RENT

4x1000W MH



TRIME

Lighting Tower Specialist



X-RENT

4x1000W MH



info contacts

+ 39 02 942 1724

info@trime.it

www.trime.it

Mast & Floodlights spare parts



Floodlight head



Lamp 1000W



Floodlight head glass



Floodlight upper support



Floodlight lower support




Anti-drag spacer



Multiposition handle



Lamp ignitor



Junction box



Coiled cable



Mast rope L.1460 mm full eyelet



Mast rope L.1440 mm full eyelet



Mast rope L.1440 mm full / dug eyelet



Mast rope L.1415 mm full / dug eyelet



Mast rope L.1385 mm full / dug eyelet



Hydraulic cylinder



Mast rotation lock pin



Bubble level



Pulley D.60




Pulley D.63

info contacts

+ 39 02 942 1724

info@trime.it

www.trime.it



X-RENT

4x1000W MH

Mast & Floodlights spare parts



Angular runner



Angular runner reinforcement



Rubber handle

Hydraulic unit spare parts



Hydraulic tank cap



Electrovalve solenoid body



Electrovalve energizing coil



Electrovalve energizing coil plug



250Bar valve

Electrical spare parts



DSE3110 controller



Fuel level gauge



RCBO 40A



16A 2 poles C.B.



Lamp switch



8 modules cover



10 modules cover




Battery charger



Light sensor



Light sensor capacitor



X-RENT

4x1000W MH



info contacts

+ 39 02 942 1724

info@trime.it

www.trime.it

Electrical spare parts



Mast control buttons



1 poles switch



Generator/Mains selector



Inlet socket 230V 32A



Outlet socket 230V 32A



Inlet socket 230V 16A



Outlet socket 230V 16A



Emergency stop button



Thermal circuit breaker



12V 70A relay



12V 30A relay



Contactor switch



Fuse holder



2A fuse



Earth post




Battery



Junction box



1000W Ballast








X-RENT


4X1000W MH

Engine spare parts

 <p>20µF capacitor</p>	 <p>40µF capacitor</p>	 <p>Fan belt</p>	 <p>Air filter external element</p>	 <p>Air filter internal element</p>
 <p>Cooling Water Expansion</p>	 <p>Fuel filter</p>	 <p>Fuel lift pump</p>	 <p>Fuel pre-filter</p>	 <p>Engine oil drain pump</p>
 <p>Oil drain pipe kit</p>	 <p>Anti-vibration buffer</p>	 <p>Oil filter</p>		

Chassis spare parts

 <p>Fuel tank cap</p>	 <p>Fuel sender unit</p>	 <p>Handle with lock</p>	 <p>Door hinge</p>	 <p>Door retention rope</p>
--	---	---	---	--



X-RENT

4x1000W MH



info contacts

+ 39 02 942 1724

info@trime.it

www.trime.it

Chassis spare parts



Stabilizer lock pin



Stabilizer beam



Stabilizer



Pin lock with spring




Plastic cover



Radiator cap cover



Radiator cap cover retention rope



Jockey wheel



AMOSS switch



Coiled cable & electrical connector for towing



Trailer socket kit



Right mudguard



Left mudguard



Wheel



White reflector




Orange reflector



Multi-function rear right light



Multi-function rear left light



TRIME

Lighting Tower **Specialist**

TRIME s.p.a.

Strada per Robecco, snc

20081 Cassinetta di Lugagnano (MI) - ITALY

Tel. +39 02 942 1724

www.trime.it - info@trime.it