

# genuine spare parts

fast moving items


**X-START**

4x1000W MH



**TRIME**

Lighting Tower Specialist



# X-START

4x1000W MH



info contacts

+ 39 02 942 1724

info@trime.it

www.trime.it

## Mast & Floodlights spare parts



Floodlight head



Lamp 1000W



Floodlight head glass



Floodlight upper support



Floodlight lower support




Anti-drag spacer



Multiposition handle



Lamp ignitor



Junction box



Coiled cable



Mast winch



Mast rope L.4300 mm full eyelet / free cable



Mast rope L.1460 mm full / dug eyelet



Mast rope L.1455 mm full / dug eyelet



Mast rope L.1415 mm full / dug eyelet



Mast winch handle



Mast rotation lock pin



Bubble level



Pulley D.60




Pulley D.62

info contacts

+ 39 02 942 1724

info@trime.it

www.trime.it



# X-START

4x1000W MH

## Mast & Floodlights spare parts



Pulley D.63



Angular runner



Angular runner reinforcement

## Electrical spare parts



Ignition switch



Hour meter



RCBO 40A



Lamp switch



8 modules cover



Glow plug signal lamp



Battery alarm lamp



Coolant alarm lamp



Oil alarm lamp



Engine protection panel



Thermal circuit breaker



Outlet socket 230V 16A




Emergency stop button



1000W Ballast



Battery



# X-START

4x1000W MH



info contacts

+ 39 02 942 1724

info@trime.it

www.trime.it

## Electrical spare parts



12V 30A relay



Junction box



Earth post

## Engine spare parts



40µF capacitor



Fan belt



Air filter external element



Air filter internal element



Engine Stop Timer



Cooling Water Expansion



Fuel filter



Fuel lift pump



Fuel pre-filter



Engine oil drain pump



Oil drain pipe kit



Anti-vibration buffer



Oil filter




Kubota lamp Timer

info contacts

+ 39 02 942 1724

info@trime.it

www.trime.it



# X-START

4X1000W MH

## Chassis spare parts



Fuel tank cap



Fuel level indicator



Handle with lock



Door hinge



Stabilizer lock pin



Stabilizer beam



Stabilizer



Rudder Stabilizer



Rudder Stabilizer handle




Wheel



Right mudguard



Left mudguard



**TRIME**

Lighting Tower **Specialist**

**TRIME** s.p.a.

Strada per Robecco, snc

20081 Cassinetta di Lugagnano (MI) - ITALY

Tel. +39 02 942 1724

[www.trime.it](http://www.trime.it) - [info@trime.it](mailto:info@trime.it)