





info contacts

4 + 39 02 942 1724

info@trime.it

www.trime.it

Mast & Floodlights spare parts



LED Floodlight 160W



Floodlight upper support



Floodlight lower support



Anti-drag spacer



Multiposition handle



Led power connector



Junction box



Coiled cable



Buble level



Mast rotation lock pin



Mast winch



Mast winch handle



Mast rope L.4300 mm full eyelet / free cable



Mast rope L.1460 mm full / dug eyelet



Mast rope L.1455 mm full / dug eyelet



Mast rope L.1415 mm full / dug eyelet



Pulley D.62



Pulley D.63



Angular runner



Angular runner reinforcement









Electrical spare parts



Ignition switch



Hour meter



RCBO 13A



Lamp switch



6 modules cover



Glow plug signal lamp



Battery alarm lamp



Coolant alarm lamp



Oil alarm lamp



Engine protection panel



Thermal circuit breaker



Outlet socket 230V 16A




Emergency stop button



12V 30A relay



Battery



Junction box



Earth post







info contacts

**** + 39 02 942 1724

info@trime.it

www.trime.it

Engine spare parts



Fan belt



Air filter external element



Kubota lamp Timer



Engine Stop Timer



Cooling Water Expansion



Fuel filter



Fuel lift pump



Fuel pre-filter



Engine oil drain pump



Oil drain pipe kit



Anti-vibration buffer



Oil filter







Chassis spare parts



Fuel tank cap



Fuel level indicator



Handle with lock



Door hinge



Stabilizer lock pin



Stabilizer beam



Stabilizer



Rudder Stabilizer



Rudder Stabilizer handle



Wheel



Right mudguard



Left mudguard



Lighting Tower Specialist

TRIME s.p.a.

Strada per Robecco, snc

20081 Cassinetta di Lugagnano (MI) - ITALY

Tel. +39 02 942 1724

www.trime.it - info@trime.it