

genuine spare parts

fast moving items




X-START

4X320W LED



TRIME

Lighting Tower Specialist



X-START

4x320W LED



info contacts

+ 39 02 942 1724

info@trime.it

www.trime.it

Mast & Floodlights spare parts



LED Floodlight 320W



Floodlight top support

Code:
LED04_C000_014ZN



Floodlight lower support

Code:
LED04_C000_011ZN



Anti-drag spacer

Code:
AS000_M023_001



Multiposition handle

Code:
AC000_M000_007



Led power connector

Code:
AC000_E006_085



Junction box

Code:
AS000_E006_004



Coiled cable

Code:
AC000_E006_016



Buble level

Code:
AC000_M016_002



Mast rotation lock pin

Code:
AC000_M000_003



Mast winch

Code:
AC000_M000_084



Mast winch handle

Code:
AC000_M000_084_01



Mast rope L.4300 mm full eyelet / free cable

Code:
AC000_M021_009



Mast rope L.1460 mm full / dug eyelet

Code:
AC000_M021_013



Mast rope L.1455 mm full / dug eyelet

Code:
AC000_M021_011



Mast rope L.1415 mm full / dug eyelet

Code:
AC000_M021_006



Pulley D.60

Code:
AC000_M021_002

Pulley D.62

Code:
AC000_M021_003

Pulley D.63

Code:
AC000_M021_008




Angular runner

Code:
AS000_M000_005



Angular runner reinforcement

Code:
PFI08_C031_012ZN



X-START

4X320W LED

Electrical spare parts



Ignition switch

Code:
K-1524863590



Hour meter

Code:
AC000_E015_009



RCBO 40A

Code:
AC000_E012_031



Lamp switch

Code:
AC000_E012_027



6 modules cover

Code:
AC000_000_037



Glow plug signal lamp

Code:
AC000_E015_014



Battery alarm lamp

Code:
AC000_E015_017



Coolant alarm lamp

Code:
AC000_E015_016



Oil alarm lamp

Code:
AC000_E015_015



Engine protection panel

Code:
AC000_E014_005



Thermal circuit breaker

Code:
AC000_E012_013



Outlet socket 230V 16A

Code:
AC000_E011_007



Emergency stop button

Code:
SI000_G006_010



12V 30A relay

Code:
AC000_E000_040



Battery

Code:
AC000_E000_027




Junction box

Code:
AS000_E006_005



Earth post

Code:
AC000_M038_035



X-START

4x320W LED



info contacts

+ 39 02 942 1724

info@trime.it

www.trime.it

Engine spare parts



Fan belt

Code:
K-1628297013



Air filter external element

Code:
K-TA04093230



Air filter internal element

Code:
K-TA04093220



Kubota lamp Timer

Code:
K-1569465990



Engine Stop Timer

Code:
K-1685160014



Cooling Water Expansion

Code:
K-EG66172400



Fuel filter

Code:
K-1522143170



Fuel lift pump

Code:
K-R140151352



Fuel pre-filter

Code:
AC000_M001_008



Engine oil drain pump

Code:
AS000_M000_060



Oil drain pipe kit

Code:
AC000_G001_001



Anti-vibration buffer

Code:
AC000_M024_054



Oil filter


Code:
K-W21ESO1600

info contacts

+ 39 02 942 1724

info@trime.it

www.trime.it



X-START

4x320W LED

Chassis spare parts



Fuel tank cap

Code:
AC000_M000_014



Fuel level indicator

Code:
AS000_M016_062



Handle with lock

Code:
AC000_M000_017



Door hinge

Code:
AC000_M000_009



Stabilizer lock pin

Code:
AC000_M000_086



Stabilizer beam

Code:
XSTART_C000_009ZN



Stabilizer

Code:
AS000_M000_048



Rudder Stabilizer

Code:
XSTART_C003_042ZN



Rudder Stabilizer handle

Code:
AC000_M000_026



Wheel

Code:
AC000_M000_042




Right mudguard

Code:
XSTART_C004_033



Left mudguard

Code:
XSTART_C004_034



TRIME

Lighting Tower **Specialist**

TRIME s.p.a.

Strada per Robecco, snc

20081 Cassinetta di Lugagnano (MI) - ITALY

Tel. +39 02 942 1724

www.trime.it - info@trime.it